

### Handle kit

The handle kit can be installed to the rear LH footpeg holder plate (18).

Undo the screw (16), and collect spring (17) to remove handle (15).

When reassembling, make sure pin (21) is in place on plate (18); if necessary, refit and drive it fully home on hole (A) on rear LH footpeg holder plate (10).

Insert spring (17) ends (B) inside hole (C) on footpeg (18).

Fit handle (15), by starting screw (16).

When installing handle (15), fit the other end (B) of spring (17) into hole (D) on handle and match pin (21) with the relevant seat on handle.

Tighten screw (16) to a torque of  $20 \text{ Nm} \pm 10\%$ .

